### QUICK•STEP® REPAIR KIT





#### **Product description**

Repair kit for damaged laminate, LIVYN or parquet floors.

#### Packaging quantity: 1

<u>Contents</u>: 1 melter, 1 cleaning comb, 1 grey sanding pad, 1 green/white pad, 7 wax blocks and 1 instruction manual.

#### **Applications**

Quick-Step® laminate, LIVYN and Parquet stand for quality. The laminate floor consists of a hard core of a high-quality HDF board, which makes the Quick-Step® floor extremely wear and impact resistant. Quick-Step® is also a laminate with an exceptionally resistant wear layer. Quick-Step® Parquet floors are composed of 100% natural materials and treated with lacquer or oil for optimal protection.

When a very sharp object falls on the floor from a fair height (e.g. the point of some scissors), it is sometimes unavoidable for the floor to sustain slight damage. The Quick-Step® Repair kit can be used to repair the light damaged area.

#### **Specifications**

## √ Matching repair

The Quick-Step® Repair Kit offers a matching solution for every Quick-Step® Laminate and Quick-Step® Parquet floor. This enables you to optimise the colour to the shade that best matches the damaged plank.

#### $\sqrt{}$ Easy and fast

The room looks nicely finished, without having to change the damaged plank.

#### $\sqrt{}$ A complete repair kit

All the elements needed for repairing every Quick-Step® floor are available in one and the same kit.

## **Instructions for use**

## 1). Preparation:

Proper preparation is important. Clean the damage on the floor first and make sure it is free from dust, oil, wax and grease.



## 2). Choose your colours:

Choose your colours according to the recommendations on www.quick-step.com



## 3). Melt and Mix



# 4). Filling



# 5). Levelling:

Use the sharp edge of the filler to scrape off excess material.



## 6). Precise adjustment:

For a precise adjustment of the wood pattern you can scratch the area to be restored with a pointed item and fill it with a darker colour.



# 7). Degrease using the grey sanding pad



# 8). Adjust the gloss level:

Use the green side of the green/white pad to make the area more glossy.
Use the white side to make it more matt.

